


# **OWNERS MANUAL**




MODEL # 12000





MODEL # 13000



MODEL # 16000

# **TABLE OF CONTENTS:**

•	TABLE OF CONTENTS	PAGE 2
•	PRODUCT INFORMATION	PAGE 3
•	SPECIFICATIONS  O VOLTAGE SUPPLY  O COMPRESSOR  O FLUID CAPACITY  INSTALATION  O WALL MOUNT  O VAULT READY  O PEDESTAL MOUNT  O ELECTRICAL INFO	
•	SETUP AND OPERATION  O REMOVING LOCKS  O DOOR DECALS  O FILLING CONTAINERS  O PROGRAMMING DISPLAY  O GENERAL START-UP	PAGE 6
•	REPLACEMENT PARTS	PAGE 9
•	GENERAL TROUBLESHOTTING	PAGE 9
•	DETAIL DRAWINGS/PARTS	PAGES 10-16

# **PRODUCT INFORMATION**

Please take a moment to fill out the information below in order to aid us with any future sales or service inquiries. Model number and serial number information can be found on the serial tag located inside the control box and/or on the lower exterior of the can. Key number can be found on the tag that comes attached to the keys. There may be more than one key number depending on unit.

Please keep this information with your records.

MODEL#:	
SERIAL#:	
KEY NUMBER(S):	
DATE PURCHASED:	
DISTRIBUTOR:	

J.E. Adams Industries 1025 63<sup>rd</sup> Ave. S.W. Cedar Rapids, IA 52404 1-800-553-8861 www.jeadams.com

#### **SPECIFICATIONS:**

SUPPLY VOLTAGE: 110VAC, 60HZ, 10A

• COMPRESSOR: 1/12HP, 110VAC, 60HZ

• SIZE: 18 x 23 x 14

CAPACITY: MODEL 16000 - TIRE SHINE
 1 GALLON TIRE SHINE


CAPACITY: MODEL 13000 - FRAGRANCE
 GALLON EACH FRAGRANCE

CAPACITY: MODEL 12000 - SHAMPOO/SPOT REMOVER/FRAGRANCE
 1 GALLON SPOT REMOVER
 1 GALLON SHAMPOO
 ½ GALLON EACH FRAGRANCE

CAPACITY: MODEL 11000 - SHAMPOO/SPOT REMOVER
 1 GALLON SPOT REMOVER
 1 GALLON SHAMPOO


#### **INSTALLATION:**

WALL MOUNT: MOUNT IS THE SAME FOR 11000, 12000, 13000 AND 16000. 12000 SHOWN BELOW




5/16-18 MAX BOLTS RECCOMENDED FOR INSTALLATION

# VAULT READY 11000, 12000, 13000, AND 16000



TOP VIEW


## **PEDESTAL MOUNT:**



- MOUNT PEDESTAL TO GROUND
- MOUNT UNIT TO PEDESTAL AND SECURE WITH 5/16-18 NUTS.

# **ELECTRICAL SUPPLY REQUIREMENT:**


- MIN 10AMP SERVICE, DEDICATED
- WIRE GAUGE TO BE CONSISTANT WITH LOCAL ELECTRICAL CODES.
- SEE DRAWING BELOW FOR WIRE INSTALLATION FOR WIRE ACCESS POINTS AND FOR WIRE HOOK UP.
- INSERT WIRE INTO TERMINAL STRIP AND SCREW INTO PLACE.



#### **SET UP & OPERATION**

NOTE: TO OPEN DOOR LOCKS TURN COUNTER CLOCKWISE 10-12 TIMES

- ATTACH DESIRED SCENT DECALS TO DOOR (12000 & 13000 ONLY)
- ATTACH DESIRED PRICING DECALS TO DOOR
- REMOVE ½ GALLON CONTAINERS FROM MACHINE. FILL WITH DESIRED SCENTS. (12000 & 13000 ONLY)
- ATTACH PICKUP HOSES TO SCENT CONTAINERS FOLLOWING DIAGRAM. TUBES LABELED THE SAME.



- 1- UPPER
- 2- MIDDLE
- 3-LOWER

SELECT SWITCH ON DOOR FRONT

- ATTACH SHAMPOO AND SPOT PICKUP HOSES TO THE 1 GALLON CONTAINERS PER LABEL ON LID (11000 & 12000 ONLY)
- DIXMOR DISPLAY PROGRAMMING WITH OPTIONAL REMOTE (8000-30) SEE BELOW
  - 1) Press the red power button.
  - 2) Timer will display 0000. At this time type in 4 digit access code. Note code will be 1234 until changed by customer.
  - 3) Once code has been entered display should read ok. If display does not read ok, repeat step 1 and 2.
  - 4) Press CH + button. Timer will display coin value. This should \$.25 and should not be changed.
  - 5) Press the CH +button. Display will now read (A: 30) or may be a different time. (A) Will be the time per coin for a single function machine. NOTE: The 12000 series is a "dual function" machine so will be applicable to step 6. Set desired time per coin by using the VOL – to decrease or the VOL + to increase. Once time is entered move to next step. (THIS STEP IS USED ON ALL MACHINES)
  - 6) Press the CH + button. Display will now read (B: 30) or may be different time. (B) Will be the time per coin for SCENT on the 12000 series machine which is a "dual function" machine. Set desired time per coin by using the VOL to decrease or the VOL + to increase. Once time is entered move to next step.
  - 7) Press the CH + button. Display will now read C. C is not use
  - 8) Press the CH + button. Display will now read D. D is not use.
  - 9) Press the CH + button. Display will now read E. E is not use.
  - 10) Press the CH + button. Display will now read F. F is not use.
  - 11) Press the CH + button. Display will now read (on A). This is the number of coins to start the primary function of the machine. Use the VOL and VOL + to adjust. Once this is done press the CH+ button and repeat for (B) which is SCENT on the 12000 "dual function" machine only. All other units (B) is non appliciable.
  - 12) Press the CH + button. Display will read bonus time. Set if desired. See explanation at the end programming instructions.
  - 13) Press the CH + button. Display will debit mode. Set if desired. See explanation at the end programming instructions.
  - 14) Press the CH + button. Display will delayed start. Set if desired. See explanation at the end programming instructions.
  - 15) Press the CH + button. Display will read HLxx. Set if desired. See explanation at the end programming instructions.
  - 16) Press the CH + button. Display will read Restart off or restart on depending on what is set. Restart off will require a person to put in full amount after unit is turned off to reactivate. Restart on allows for

- additional coins to be put in the machine to keep unit running. To set use VOL or VOL + to change.
- 17) Press the CH + button. Display will now read STD or USER or MIX. To make a custom message use VOL + button to scroll to USER. At this point press and hold CH + button until original message appears. At this time you may change the message simply by using the VOL or VOL + buttons to change letters. Once message has been entered you must put the symbol / at the end of message. This will tell display that this is the end of the message.
- 18) Press the CH + button now 5 more times to exit programming.
- 19) Unit should now be programmed.

### Program definitions:

## Bonus time settings:

- Amount of time set in bonus time is added to regular time per coin/pulse(e.g. if you want to give 45 seconds for bonus time and your regular time per coin is 30 seconds, you would set bonus time at 00:15)
- > Bonus is disabled by setting bonus time to 00:00.
- ➤ If bonus time is set to less than one minute, bonus time is added when bonus coin is reached and every coin after that until time expires.
- ➢ If bonus time is set at 1:00 or more, bonus will be a "one time" bonus. Bonus time will only be added for bonus coin or multiplies of bonus coin (e.g. 16<sup>th</sup> coin, 32<sup>nd</sup> coin, etc). Any other coin will on receive regular time per coin.
- ➢ If bonus time is set to 99:00, when bonus coin is deposited, timer will show "-on-" and timer will continue to run until coin switch wire is shorted to ground by a loop detector or other switch closure for a minimum of two seconds.

#### Debit and credit mode:

- ➤ Debit mode: As coins are deposited display shows "\$1.75 MORE, \$1.50 MORE, \$1.25 MORE" etc. until start price is reaches. Once start price is reached display switches to time accumulating until no more coins have been deposited.
- Credit mode: As coins are deposited display shows money accumulating (\$.25, \$.50, \$.75 etc). If timer is also set to delayed start mode timer will continue to show money accumulating until no more coins have been deposited. If timer is set to instant start, as soon as start price is reached, timer will change to time counting down.
- ➢ Both mode: As coins are deposited display shows money accumulating (\$.25, \$.50, \$.75 etc). If start price is not reached, after 5 seconds timer will alternate between "add \$x.xx more" and amount of money already deposited.

### Display programming with push button:

Unit can be programmed using buttons that are located inside display. One is labeled S2, which is used to change from item to item. One is labeled S1 which is used to set desired value. If you hold down S1 this

- will cause numbers to decrease. If you repeatedly push S1 numbers will increase.
- ➤ When programming with buttons use same instructions as remote except for the following. Where it says to press CH + use S2 and where it says to use VOL + or – use S1.
- START MACHINE AND SELECT SHAMPOO/SPOT FUNCTION. RUN BOTH SHAMPOO AND SPOT SELECTIONS UNTIL AIR IS COMPLETELY BLED FROM SUPPLY TUBES (11000 & 12000 ONLY)
- SELECT FRANGRANCE SELECTION. START MACHINE AND OPERATE EACH SELECTION UNTIL AIR IS COMPLETELY BLED FROM THE SUPPLY TUBES (12000 ONLY)
- TURN MACHINE ON AND CYCLE UNTIL AIR IS COMPLETELY BLED FROM LINES (13000 & 16000 ONLY)
- CLOSE AND LOCK DOOR AND PLACE INTO SERVICE.

#### MAIN REPLACEMENT PARTS:

9500-43 PERSTALTIC PUMP

8843 FILTER

8802-1 LOCKING CAP

8549 FLEX STRAIN RELIEF

8824 COMPRESSOR

8131-2 TRANSFORMER

8760 RELAY

5979D2 FUSE


5914 ROCKER SWITCH

8844 AIR SOLENOID (12000 UNIT ONLY) FOR ANY PARTS NOT LISTED CALL J.E. ADAMS

#### TROUBLESHOOTING:

UNIT WONT RUN	CHECK CIRCUIT BREAKER
	2) CHECK FUSE IN MACHINE
	<ol><li>CORRECT NUMBER OF COINS</li></ol>
	DEPOSITED
	4) MAKE SURE POWER SWITCH IS ON
SHAMPOO/SPOT NOT WORKING (11000 &	CHECK THAT ALL AIR IS REMOVED
12000 ONLY)	FROM SUPPLY TUBES AND CAPS
	ARE TIGHT ON CONTAINERS
	2) CHECK FLUID LEVELS IN
	CONTAINERS
	3) ENSURE SELECTOR SWITCH IS IN
	PROPER POSTION
	4) VERIFY PERISTALTIC PUMPS ARE
	WORKING
FRAGRANCE NOT WORKING (12000 &	ENSURE SELECTOR SWITCH IS IN
13000 ONLY)	PROPER POSTION
·	2) CHECK FLUID LEVEL IN
	CONTAINERS
	3) CHECK THAT ALL AIR IS REMOVED
	FROM SUPPLY TUBES AND CAPS
	ARE TIGHT

PART				BILL OF MATERIALS					BILL OF MATERIALS		
j	\0001.I	ITEM	PART NUMBER	ER DESCRIPTION	NOIL	QTY	ITEM P	PART NUMBER	DESCRIPTION	ON	QTY
			1079-3	GASKET		74"		11000-1W	CABINET WELDMENT		-
		40	3100	1/4" CLEAR TUBING		09	2 11	11000-5A-1	CONTROL PLATE ASSEMBLY	EMBLY	-
		4	3105	3/16" OD TUBING		12"		5604D1	#10-24 x 1/2 CARR BOL	<u></u>	9
			8000-23	5 POLE FEMALE CONN	ZZ	-		5611D2	NUT. 10-24 UNC KEPP- ZINC	ZINC	16
			5901D5	WIRE NUT		2		11000-4A	COMPRESSOR ASSEMBLY	IBLY	-
			5721D2	HEAT SHRINK TUBING	S	20		11000-10w	BRACKET WELDMENT, SHAM	SHAM	-
									HOLDER		
								8678	HOSE HANGER		-
							8 56	5601D8	1/4-20 x 3/8 HHCS-ZINC PLATED	PLATED	4
								11000-11A-1	DOOR ASSY, FRAGRANCE	NCE	-
							10 85	8549-1	FLEX STRAIN RELIEF		-
			(				11 11	11000-15	SHAMPOO BRUSH ASSEMBLY	SEMBLY	-
			( 6 )					8204RW	WELDMENT, COIN BOX	~	-
								8638	PIN LOCK		-
								5644D2	CAGE NUT		2
			Æ			27	T	11000-22	UNION 1/8 PUSH LOCK FITTING	FITTING	-
								8157	NUT, #6-32 KEPP NUT STAINLESS	STAINLESS	2
							T	11000-6w	BRACKET WELDMENT		2
								5636D1	#10-24 PHIL. PAN HEAD SCREW	) SCREW	9 ,
							T	11000-53A	PUMP BRACKET ASSEMBLY	MBLY	-
	0		_				T	29000-59	VALIDATOR FACEPLATE HANDLE	IE HANDLE	-
							77	29000-45W	VALIDATOR FACEPLATE WELDMENT	Ш	<del>-</del>
					С			29000-44W	VALIDATOR BOX WELDMENT	OMENT	-
					\{\{\}			5644D1	CAGE NUT		-
	[		0					8958-1	MEDECO SCREW LOCK	¥	-
	0 0							8130-6	MARS 110V BILL VALIDATOR	ATOR	-
		}						5603D9	10 Std NF Nylock Nut		2
	Juan						27 29	29000-42W	MOUNTING BRKT, WELDMENT	DMENT	-
			aaa )					11000DBLUE	DECAL, 16000, BLUE		-
			-					9500-47	STAINLESS TUBE WEIGHT	GHT	2
								8843	DEBRIS FILTER		2
			<b>-</b> (F	J.				8802-1	BOTTLE CAP, DRILLED		2
	NAAA!		ANN!					8036	NUT, 1/4-20 UNC KEPS	A	ω .
								9500WIN	WINTER SHAMPOO FORMULA	RMULA	
							37 11	11000SPOT	SPOT REMOVER FORMULA	MULA	
			J					2-70	1000 - 14		-
	30)						TITE			N/V/2	
	)		-	<b>.</b>			0	AMPOO		NE W/VA	_
							UNSPECIFIED	ED MATERIAL ES		CEDAR RAPIDS, 10WA	OWA
∢	5267	ADD 4 NL	ADD 4 NUTS FOR VALI	ALIDATOR BRACKET	090109	냭	1 PL ±.030	30 SCALE			<u>(</u>
REV	NO.		DESCI	SCRIPTION	DATE	ВУ	2 PL ±.010	O DRAWN BY		8 1 1 1 8 3 1 4 1 8	<b>)</b> °
	THIS DOCUMENT SHALL N	NOT BE REI	PRODUCED NC	THIS DOCUMENT SHALL NOT BE REPRODUCED NOR SHALL THE INFORMATION THEREIN BE	ON THEREIN BE		3 PL ±.003	DATE	PART	, 1000	REV.
	USED BY OR DISCLOSED TO OTHERS EXCEPT	TO OTHER		AS AUTHORIZED BY J.E. ADAMS INDUSTRIES	<b>MS INDUSTRIES</b>		ANGLE ±1.0			110001	⋖



PART NO.	100001			BILL OF MA	-	Н		BILL OF MATERIALS	TERIALS	
	12000	LEM			ΔIY	IY ITEM			DESCRIPTION	γIα
		38	9500WIN	WINTER SHAMPOO FORMULA	-	1			VELDMENT	-
		39	11000SPOT	SPOT REMOVER FORMULA	_	1	12000-5A-1		CONTROL PLATE ASSEMBLY	_
		40	11000-23	3/16" UNION PUSHLOCK	1	1 3	5604D1	#10-24 × 1/2	#10-24 x 1/2 CARR BOLT	9
		41	1079-3	GASKET	74"	4		NUT, 10-24	NUT, 10-24 UNC KEPP- ZINC	16
		42	8000-23	FEMALE 5 POLE CONN	-	1 5	11000-4A	COMPRES	COMPRESSOR ASSEMBLY	-
		46	5901D5	ORANGE WIRE NUT	(1)	5 6	11000-10w	BRACKET \	BRACKET WELDMENT, SHAM.	1
		47	3100	1/4" RUBBER TUBING	15	_		HOLDER		
		48	3105	3/16" OD PLASTIC TUBING	12"		8678	HOSE HANGER	IGER	2
		49	8829	SCENT, NEW CAR	-	1 8	5601D8	1/4-20 x 3/8	1/4-20 x 3/8 HHCS-ZINC PLATED	4
		20	8865	SCENT, VANILLA	_	1 9	12000-11A-1		SEMBLY,	-
		21	8857	SCENT, WILD CHERRY	_			SHAM-SPOT-FRAG	JT-FRAG	>
		40	5644D2	CAGE NUT	2	10		FLEX STRAIN RELIEF	AIN RELIEF	-
		25	5721D2	HEAT SHRIK TUBING	20	0" 11	11000-15	SHAMPOO	SHAMPOO BRUSH ASSEMBLY	-
						12		WELDMEN.	WELDMENT, COIN BOX	-
						13		PIN LOCK		-
						14		UNION 1/8	UNION 1/8 PUSH LOCK FITTING	1
						15		NUT, #6-32	NUT, #6-32 KEPP NUT STAINLESS	2
		A	<u> </u>	0		16		BRACKET \	BRACKET WELDMENT	-
		<u>a</u>				17	7 5636D1	#10-24 PHII	#10-24 PHIL. PAN HEAD SCREW	9
		_				18	3 12000-6A	BRACKET ASSEMBLY	ASSEMBLY	1
				(2)		19	9 8898-1	FRAGERAN	FRAGERANCE GUN ASSY750 OD	-
	0							HOSE		
				(		20		PUMP BRA	PUMP BRACKET ASSEMBLY	-
				0		21	1 28000-40	PLASTIC C	PLASTIC CONTAINER	2
						23		BOTTLE CA	BOTTLE CAP, DRILLED	2
	0 0					24		STAINLESS	STAINLESS TUBE WEIGHT	2
	a					25			LTER	2
			- Anna	li a		28			MOUNTING BRKT, WELDMENT	-
			)		)	29		10 Std NF Nylock Nut	Aylock Nut	2
						30	8130-6	MARS 110V	MARS 110V BILL VALIDATOR	-
						31	1 8958-1	MEDECO S	MEDECO SCREW LOCK	-
	mg/y		- u=13	0.54		32	2 5644D1	CAGE NUT		1
			- C	-		33			VALIDATOR BOX WELDMENT	-
						34	t 29000-45W		VALIDATOR FACEPLATE	-
						Č		WELDMEN		,
						S S			VALIDATOR FACEPLATE HANDLE	- ,
	0					35				- 0
						3	8030	NOI, 1/4-20	NOT, 1/4-20 UNC KEPS	o C
					)	TITLE		MPOO-SP	SHAMPOO-SPOT MACHINE	
				,						
					)	UNS	UNSPECIFIED MATERIAL TOLERANCES	AL	CEDAR RAPIDS, IOWA	S, IOWA
∢	5269	ADD 4 N	ADD 4 NUTS FOR VALID	VALIDATOR BRACKET	090109	JF 1PL	±.030			(f
REV	NO.		DESCR	ESCRIPTION	DATE	BY 2PL	±.010 DRAWN	L		6 2 1 . 8 3
	THIS DOCUMENT SHALL	NOT BE R	REPRODUCED NOF	THIS DOCUMENT SHALL NOT BE REPRODUCED NOR SHALL THE INFORMATION THEREIN BE	IN BE	3 PL	±.003	L NILOS	PART	REV.
	USED BY OR DISCLOSED	D TO OTHE	ERS EXCEPT AS A	USED BY OR DISCLOSED TO OTHERS EXCEPT AS AUTHORIZED BY J.E. ADAMS INDUSTRIES	RIES	ANG		6/16/2009	120007	<

10000		9	BILL OF MATERIALS	-		275	B	BILL OF MATERIALS	555
130000	ITEM	PART NUMBE	DESCRIPTION	ΔT	Y ITEM		PART NUMBE	DESCRIPTION	Z To
	38	29000-44W	VALIDATOR BOX WELDMENT	-	-	1100	11000-1W	CABINET WELDMENT	
	38		CAGE NUT	-	2		13000-5A-1	CONTROL PLATE ASSEMBLY	
	40	8958-1	MEDECO SCREW LOCK				101	#10-24 x 1/2 CARR BOLT	9
	41	8130-6	MARS 110V BILL VALIDATOR	-			D2	NUT 10-24 UNC KEPP. ZINC	16
	42	5603D9	10 Std NF Nylock Nut	2			11000-4A	COMPRESSOR ASSEMBLY	-
	4	8157	NUT, #6-32 KEPP NUT	4				HOSE HANGER	4
			STAINLESS		8	5601D8	D8	1/4-20 x 3/8 HHCS-ZINC PLATED	4
	45	29000-42W	MOUNTING BRKT, WELDMENT				13000-11A-1	DOOR ASSY, FRAGRANCE w/VAL	-
	47	8036	NUT, 1/4-20 UNC KEPS	8	12	8204RW	RW	WELDMENT, COIN BOX	-
	48	5721D2	HEAT SHRINK TUBING	20.	13	8638		PINLOCK	-
					16		11000-6w	BRACKET WELDMENT	2
					17	5636D1	101	#10-24 PHIL, PAN HEAD SCREW	9
					19	8898-1	3-1	FRAGERANCE GUN ASSY, 750	
		<b>@</b>			8			OD HOSE	
					8		13000-53A	PUMP BRACKET ASSEMBLY	-
	ā		•		21	7	13000DBLUE	DECAL, 13000, BLUE	-
			1		28		28000-40	PLASTIC CONTAINER	e
0 0			-		32		2-1	BOTTLE CAP, DRILLED	60
					33		747	STAINLESS TUBE WEIGHT	9
					S.			DEBRIS FILTER	6
		0	7		38		1D2	CAGE NUT	CI
0 0	80	9			38			1/4" RUBBER TUBING	90-
0				_	49	3105	1	3/16" TUBING	12"
ļun			2	_	37		D5	ORANGE WIRE CONNECTOR	2
	-				38	8000-23	1-23	FEMALE 5 POLE CONN	1
	0				39	1079-3	3.3	GASKET	74"
					40	8829		SCENT, NEW CAR	
					4	8865	1	SCENT, VANILLA	***
					42		230	SCENT, WILD CHERRY	***
					43		1-56	WIRING HARNESS, VALIDATOR	-
					38		29000-59	VALIDATOR FACEPLATE HANDLE	-
					37	2.31	29000-45W	VALIDATOR FACEPLATE WELDMENT	-
7			3		TITLE	41000	FRAG	FRAGRANCE MACHINE	
8				3	TOLE	UNSPECIFIED	MATERIAL	COLONI PANCIA. JOHN	1
5271	ADD 4 N	ADD 4 NUTS FOR VALIDATOR BRACKET	TOR BRACKET 090109		JF + PL	+.030	SCALE		8
REV NO.		DESCRIPTION	TION DATE		BY 2PL	4.010	NAME OF STREET		3:
THIS DOCUMENT SHALL NOT BE REPRODUC	SHALL NOT BE R	EPRODUCED NOR 8	ED NOR SHALL THE INFORMATION THEREIN BE	W1-	3.5	3 Pt. ± 003	DATE THE STATE	130007	NEV NEV
COUNTY OF STREET		the same of the owner, is the name of	のできるとは、 は、 でき は、 は、 でき は でき		COMP				

