


# PARTS LIST

## MODEL 2600-05 FLEX-A-LITE FOGGER

Item	Part No.	Description	Q/U
1	2332	Clip	1
2	2334	Spring	1
3	2346	Venturi	1
4	2331	Valve Rod/Knob Assy.	1
5	2330	O-Ring	1
6	2333	Sleeve	1
7	2329	Screw	2
8	2352	Screw	2
9	2357	Hex Nut	2
10	2359	Spacer	1
11	2353	Nozzle	1
12	1433	Spring Clamp	2
13	2354	Screw	6
14	2385-48	Flex Hose Assy.	1
15	2326	Flat Washer	1
16	2308	Screw	4
17	2349	Pressure Tube, Upper	1
18	2374-54	Supply Tube, Upper	1
19	2314	Electric Cord, 110VAC	1
	2341	Electric Cord, 220VAC	1
20	2311	Switch 110VAC	1
	2340	Switch, 220VAC	1
21	990	Boot f/Switch 220 VAC	1
22	2315	Strain Relief	1
23	1103	Closure	1
24	1128	O-Ring	1
25	2358	Tube Retainer	1
26	2319	Pressure Tube, Lower	1
27	2312	Strainer	1
28	2316	Wire Connector	2
29	1241	Tank Barb	2
30	1246	Angle Barb	2
31	2375	Supply Tube, Lower	1
32	1614	Ins. Flag Term. ground	1
33	2323	Motor, 110VAC	1
	2324	Motor, 220VAC	1
34	2305	Motor Guard	1
35	2306	Screw	2

Item	Part No.	Description	Q/U
36	2405	Tank	1
37	2408	Housing	1
38	1145	Screw	2
39	2355	Mount Plate	1
40	29108123	1/4" Nylon Spacer	4



135 Region South Drive, Jackson, GA 30233  
 678-688-5601 • www.bgequip.com