

GE Sensing



Protimeter Hammer Electrode Pins

The insulated needles in your Hammer Electrode are made from the finest materials, Nonetheless, it is possible to break them if care is not taken to hammer them straight in and hammer them out. Never apply leverage.

To replace needles:

Use the supplied tool on the top handle to unscrew the used pins. Screw in new pins using the same being careful not to damage the insulated coating.

When the hammer is not in use keep the protective cap over the pins to prevent injury and the pins.

Replacement pins in 10 packs can be purchased from your local distributor or directly from GE Sensing.

Part no. BLD05296

Americas (1) 800 321 4878, UK +44 (0) 1628 472722

Germany + 49 (2129) 55810