
HydraFRESH LVC



Restorative Cleaner for Tile, Laminate, and Luxury Vinyl Plank Floors

Restoring the appearance of your luxury vinyl plank or luxury vinyl tile flooring investment to "like-new" condition is more than just cleaning.





- Can be used as part of a prespray and rinse system or as part of a no rinse system.
- Neutral PH makes it safe for luxury vinyl plank and tile floors, resilient tile floors and wood (polyurethan finish only) and laminate floors.
- HydraFresh LVC allows you to extend the life of the flooring investment and keep it looking great all the time.





Available in: 1 Gallon, Case of 4 x 1 Gallon, 1 Quart, 4 x 1 Quart Case

Part # 800-142

Directions:

Please read the full label directions before cleaning.

- 1. Sweep or vacuum floors prior to deep cleaning to remove particulate soils. An untreated microfiber dust mop works well for this. HydraFRESH LVC can be used in conjunction with a counter rotating brush agitation system with the appropriate brushes, an auto-scrubber; a mop and rinse system, and where the construction of the floor and the adhesives allow, a rotary hard surface cleaning tool such as the RX15H Rotary Hard Surface Tool, the RX20 NEXT GEN with hard surface attachments; or a stationary hard surface wand.
- For normal soiling, Mix 1 part HydraFRESH LVC with 64 parts water into sprayer (2 ounces
 of solution/gallon of water). For heavy soiling, mix 1 part HYDRAFRESH LVC with 16 parts
 water (16 ounces of solution/gallon of water).
- 3. Apply with sprayer or mop
- 4. Allow several minutes of dwell time but do not allow solution to dry.
- 5. Ground in soiling in grooves and textured surfaces may require agitation with a counter rotating brush system with appropriate brushes
- 6. Agitate and extract cleaning solution using high pressure warm or hot water from RX15H Rotary Hard Surface Tool or a RX20 NEXTGEN with a hard surface attachment, or high pressure hard surface wand. For more sensitive surfaces, consider using a hard surface wand or simply mop with clean water and rinse. Consult with the flooring manufacturer directions for further information on what rinse or extraction system to use.
- For faster drying, especially in humid environments, consider the use of an axial, centrifugal, or downdraft air mover after cleaning.







