

8149 Coin Mechanism




Coin return button, push to operate.

Simply pushing the coin return button can often clear coin jams in the unit.

Hinged cleanout
door.




Coin trip wire.



Hinged cleanout door in open position, open door to clear coin jam and clean sides with household cleaner if necessary.

Throat adjustment
screw.



If coins jam here, loosen screw and
move slightly right, re-tighten screw.

Loosen adjustment screw to slide pointer right or left.

Trip wire.

If coins jam near the trip wire, move pointer slightly to the right or left to adjust.

Pointer

