
Focus II Rider How To

Prepare for Use



Check batteries, turn on switch to check battery indicator (battery fully charged).



Select

2

5

2

Select proper brush, inspect then Install brush (Disc System) under scrub deck. Align brush gimbal (push until it locks).



Install pad (Boost System) by first removing the side skirt. Line up pad with the fixed pad drive then press into place.

Install rear squeegee.
Do not over tighten.
Connect the recovery
hose to the squeegee
inlet.

4



Make sure ball float system and debris catch cage is clean.

6

Fill with water (Below 130 °F); add detergent (follow dilution ration).

Machine Operation

Familiarize yourself with the control panel and all of its functions for scrubbing and transporting.



Press the Solution Control and Scrub switch. Adjust the Solution Control as needed.

Begin scrubbing process.

Focus II Rider How To

Store the Machine

1



Empty and rinse recovery tank, catch cage and ball float.

2



Remove, rinse and inspect rear squeegee.

3



Remove, rinse and inspect brushes or pads.

4



Empty and rinse solution tank with clean water. Wipe down the exterior of the machine as necessary.

5



Drain water into an open drain.

6



Wipe exterior of the machine.

7



Charge machine for next shift.

Maintenance√

Daily Maintenance:

- Charge Batteries
- Check/clean tanks & hoses
- Check/Clean/rot ate brushes/pads
- Check/Clean squeegee
- Check/Clean shut-off float
- Empty/clean debris catch cage

Weekly:

- Check battery cell water level
- Inspect scrub housing skirts
- Inspect/Clean Solution filter
- Purge Detergent System

Periodically:

- Lubricate machine - Monthly
- Check carbon brushes Yearly

