

>



Model Number: AH17

Clean Storm AH17 Auto Defoamer Attachment 2in Port N11-26 Needle Valve Vacuum Injector

Manufacturer: Clean Storm

Clean Storm Defoamer Attachment 2" Port N11-26



Uses vacuum to suck in liquid defoamer into the machine.
Needle valve adjustment for flow control.
Does not include the Velcro Hose Hook

>

Can be used on CFR machines to inject liquid oxygen or Hydrogen Peroxide into the water.

Optional

Steambrite AH95 Stair Hose Hook with Velcro Strap

MADE WITH THE FOLLOWING PARTS:

Mytee B112 1/8" Fip Screwed Bonnet Brass Needle Valve 122440

1/8in Mip X 1/4in Fip Brass Adapter Reducing 28191L 140653
9.803-054.0

>

1/8in Mip X 1/4in Barbed Brass Fitting AKA 32004 BR010 A00076
9.802-137.0

Clear Condensate Drain Tubing 1/4in ID X 3/8in OD X Per foot Vinyl
and Chemical Injection 20140918

>

Plastic Chemical strainer filter with 1/4" barbed connection 85300050

Cuff: 2in Thread X 2.0in Slip - Standard 2in Vacuum Hose Cuff [AH44]
8.708-904.0 B016 J11630

2 UNITS USED

Hose Vacuum Hose 2.0in ID Double Lined By The Foot 20140808 (NO
Hose Cuffs)

>

20141014 2in OD Slip X 2in OD Slip White Plastic Vacuum Hose Connector

Built it yourself parts total \$43.29. Assembly Labor time 20 minutes.

Availability: This product was added to our catalog on Thursday 19 May, 2011