

>



Model Number: 20161206

Harvard Chemical 20161206, CRB and VLM Encapsulation Cleaner, Combination Bone Dry, Plus Control

Manufacturer: Harvard Chemical Research

Harvard Chemical 20161206 CRB and VLM Encapsulation Cleaner Combination Bone Dry Plus Control

Harvard Chemical 180001: Bone Dry Encapsulation Cleaner 1 Gallon
Description

Bone Dry is a highly effective low moisture cleaner for carpets and rugs including 5th generation nylon. This product is highly effective in hot or cold water and contains emulsifiers that break down dirt, grease, oil, food residue and "wicked back" stains. Bone Dry contains special polymers that engulf and encapsulate dirt, detergent residue and other soils then dries to a brittle non sticky crystal. The crystal and entrapped soils are easily removed by routine vacuuming.

Features

- Dries to a crystalline solid
- Quickly breaks down stubborn dirt, grease, and oil
- Low Moisture, carpets are back in service quickly
- Prevents fiber re-soiling from sticky residues
- Prevents "wick back" of spots
- Safe on 5th generation carpets

Specifications

Appearance: Clear Liquid
Odor: Slight ammonia
Specific gravity: 1.01
PH 10% Solution: 8.8 - 9.3
Flammable: No
Detergency: Excellent

Harvard Chemical 400518 Control Dry Cleaning Absorbent Powder Carpet Cleaner Compound 15 lbs

Description

Control is a dry extraction carpet cleaning compound designed specifically for carpets. Dry extraction cleaning is an easy and safe system that effectively cleans soiled areas, spots, and spills. Problems associated with wet cleaning methods are not found in this system because the product remains dry. Because this product is not liquid in nature, a long drying time is not required. This allows the immediate use of the carpet. Carpet may be walked on even during the cleaning process with no adverse effects. The active ingredients in this mixture emulsify and hold soils and may be removed by vacuuming when dry. Due to this quick application and drying time no residue is left behind to result in resoiling. The dry cleaning of carpets is

>

recommended by many carpet manufacturers worldwide. Each pound of product cleans a 50 square foot (5 ft X 10 ft) area. For large areas, use with a Control Dry Cleaning Machine to remove dirt and grime from heavily soiled walk lanes, carpeting, and area rugs. This product is available in two sizes a one pound bag and a fifteen pound container for larger areas.

Recommended by dozens of carpet manufacturers worldwide to deep clean all types of carpet, including stain resistant fibers.

Features

- Eliminates over wetting
- Reduces cleaning time
- Cleaned carpets back in service quickly
- Use for large areas or spot cleaning
- Emulsifies oil and grease
- Does not promote re-soiling

Specification

Appearance:	Light Golden Brown
Odor:	Citrus
Specific gravity:	NA
pH:	Neutral
Biodegradable:	Yes
Emulsification:	Excellent

Directions

- Vacuum Carpets
- For cleaning dilute 8 ounces of Bone Dry per gallon of water.
- Apply Bone Dry solution with a pump up sprayer or traditional shampoo shower feed.
- Apply / Sprinkle Control to the carpet over the Bone Dry
- Agitate together with your CRB, VLM, or floor machine
- Allow this product to completely dry.
- Pick up powder with CRB, VLM, and / or vacuum cleaner.

NOTE: If spot or spill is severe, pretreat using Bond Dry diluted 1:5 with water and add more Control if needed to remove the entire spot. Do not rub too aggressively or damage to carpet may occur.

Includes

>

Harvard Chemical 400518 Control Dry Cleaning Absorbent Powder Carpet Cleaner Compound 15 lbs

Harvard Chemical 180001 Bone Dry Encapsulation Cleaner 1 Gallon - 4001

Safety Cautions
Keep out of reach of children!

Prior to using this or any cleaning product, make sure employees read and understand the hazard information found on the product label and Material safety data sheet. (MSDS). The label and MSDS will also provide information on handling precautions, protective equipment and first aid instructions which might be appropriate for this product.

After opening Control secure lid tightly to keep from drying out. This product is nontoxic by oral ingestion or by inhalation, however persons with unusual skin sensitivity should avoid direct contact. Avoid using in confined areas if you have respiratory problems. Neutral pH. In case of contact with eyes rinse to remove particles. If irritation persists, or if swallowed call physician.

Bone Dry MSDS
Control MSDS

Bone Dry Technical Specs and Instructions
Control Technical Specs and Instructions
Optional
Used with CRB and VLM machines

Clean Storm CRB17 Wide Pre-Scrubber and Dry Cleaning Machine FREE
Shipping And FREE Power Cord

>

Availability: This product was added to our catalog on Tuesday 06 December, 2016

Steambrite Supply